



## Why is the Batch Size field in the batch record always 0?

Batch Size is a parameter which is only obtained from the Master Recipe. By default this field is set to 0.

In CENTUM CS3000 Batch and CENTUM VP Batch this is only an information field and may not actually be used by a specific project. It is therefore not often given a value.

If this information is required in Exaquantum/Batch then the Master Recipe will need to be modified using the Recipe Builder on the Engineering Workstation Station and downloaded. It cannot be changed on a per Control Recipe (Batch) basis.

Exaquantum /Batch Releases Affected
All