

How do you configure Independent Layers of Protection (ILP) for SFM?

ILPs are defined in the Safety Requirements Specification. This ILP information needs to be included in the SFM configuration file (Excel spreadsheet), this is the same for configuring initiating causes, SIF conditions, Actuating devices etc.

Please note that on the top of configuring ILPs in the SFM LOPA file, you should configure SER filters which correspond to the LOPA file ILP definitions.