Knowledge

Base



ARA R3.30 Installation Fail on Microsoft Windows Server 2012 Editions

KB-1089-22

Document Summary		
Article Type	User Guide	
Products Affected	Exaquantum/ARA	
Versions Affected	R3.30	
Function Affected	Installation on Windows Server 2012 & R2	
Available Resolution	Install Microsoft Windows Management Framework 5.1	
Audience	System Integrator, Administrators	
Summary	Exaquantum/ARA R3.30 requires a more recent version of PowerShell than shipped with Windows Server 2012 & R2. If PowerShell is not updated, an error is seen on installation.	
Review Date	Document to be reviewed before December 2023	

Table of Contents

Table of Contents	1
Chapter 1 Introduction	2
1.1 Audience	
Chapter 2 Issue Description	3
Chapter 3 Issue Resolution	4
Chapter 4 Further Reading	5
Copyright and Trademark Notices	6
Highlights	7

Chapter 1 Introduction

When installing the Exaquantum\ARA R3.30 software on a server with the operating system Microsoft Windows 2012 or Microsoft Windows 2012 R2, the install will fail and rollback.

This is due to ARA R3.30 requiring a newer version of Powershell than the one shipped with Microsoft Windows 2012

This document will detail how to resolve the error encountered.

1.1 Audience

This guide is intended for system integrators and administrators.

Chapter 2 Issue Description


When installing the ARA product, PowerShell version 5 is a minimum requirement. Windows Server 2012 includes PowerShell version 4 and requires updating to successfully install.

Chapter 3 Issue Resolution


To resolve the issue, the latest version of Windows Management Framework can be installed to update the version of Powershell.

The Microsoft installer can be downloaded from the below website:

https://www.microsoft.com/en-us/download/details.aspx?id=54616



- 1. Go to the download section (by selecting the Download button).
- 2. Select the download required for the operating system in use.



- 3. Install the required update on the Exaquantum/ARA R3.30 server.
- 4. Retry the installation of Exaquantum/ARA.

Chapter 4 Further Reading

There is additional information regarding this Microsoft update on the website under the Details section:

https://www.microsoft.com/en-us/download/details.aspx?id=54616

For further information please visit the Yokogawa Marex support website or contact YMX at the support@ymx.yokogawa.com email address.

The Yokogawa Marex support website is available at https://ymx.yokogawa.com/support

The Yokogawa Marex Knowledgebase is available at https://ymx.yokogawa.com/knowledge-base

Copyright and Trademark Notices

© 2022 Yokogawa Electric Corporation

All Rights Reserved

The copyright of the programs and online manuals contained in the software medium of the Software Product shall remain with YOKOGAWA.

You are allowed to print the required pages of the online manuals for the purposes of using or operating the Product; however, reprinting or reproducing the entire document is strictly prohibited by the Copyright Law.

Except as stated above, no part of the online manuals may be reproduced, transferred, sold, or distributed to a third party in any manner (either in electronic or written form including. without limitation, in the forms of paper documents, electronic media, and transmission via the network).

Nor it may be registered or recorded in the media such as films without permission.

Trademark Acknowledgements

- CENTUM, ProSafe, Exaquantum, Vnet/IP, PRM, Exaopc, Exaplog, Exapilot, Exasmoc and Exarge are registered trademarks of Yokogawa Electric Corporation.
- Microsoft, Windows, Windows Server, SQL Server, Excel, Internet Explorer, SharePoint, ActiveX, Visual Basic, Visual C++, and Visual Studio are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Adobe and Acrobat are registered trademarks of Adobe Systems Incorporated and registered within particular jurisdictions.
- Ethernet is a registered trademark of XEROX Corporation.
- All other company and product names mentioned in this manual are trademarks or registered trademarks of their respective companies.
- We do not use TM or ® mark to indicate those trademarks or registered trademarks in this manual.
- We do not use logos in this manual.

Highlights

The Highlights section gives details of the changes made since the previous issue of this document.

Summary of Changes

This is Issue 1.0 of the document related to Product Library version 1.0.

Detail of Changes

The changes are as follows:

Chapter/Section/Page	Change