

Exaquantum History Catch-up failure from ExaOPC-RD

KB-1094-22

Document Summary	
Article Type	User Manual
Products Affected	Exaquantum/PIMS/ExaOPC-RD
Versions Affected	R2.85 or later
Function Affected	History Catch-up
Available Resolution	Increase ExaOPC-RD HDA Timeout
Audience	Administrators
Summary	<p>Exaquantum History Catch-up from ExaOPC-RD Server fails with the following error in the application event log:</p> <p>Q:\Exaquantum\QOpcManager\QOPCDAManager\OPCHDAServer.cpp</p> <p>Line 221 : OPCDAManager general error : : GetItemHandles() failed, node = OPCSERVER, progid = Yokogawa.ExaopcHDARD1 hr = 0x8001011f : R3.30 : 2022/10/05 07:58:10.981</p> <p>This can be resolved by increasing the ExaOPC-RD HDA timeout .</p>
Review Date	Document to be reviewed before January 2024

Blank Page

Table of Contents

- Table of Contents 1
- Chapter 1 Introduction 2**
 - 1.1 Audience..... 2
- Chapter 2 Issue and Resolution 3**
 - 2.1 Issue Description 3
 - 2.2 Logged Errors 3
 - 2.3 Resolution..... 4
 - 2.4 Additional Steps (if required) 5
- Chapter 3 Further Reading..... 6**
 - Copyright and Trademark Notices 7
 - Highlights..... 8

Chapter 1 Introduction

History catch-up from ExaOPC-RD, after a period of Exaquantum downtime, fails leading to an aborted start-up.

HDA data for the downtime period is still available and accessible locally on the ExaOPC Servers used in the ExaOPC-RD pair(s).

This document describes how to resolve the History Catch-up issue.


1.1 Audience

This guide is intended for system administrators.

Chapter 2 Issue and Resolution

2.1 Issue Description

Retrieval of HDA data from ExaOPC-RD fails on the Exaquantum server during History Catch-up resulting in an aborted Exaquantum start-up.



Exaquantum can only be started by disabling History Catch-up on Start-up.

The issue is caused by the ExaOPC-RD Server failing to get information about the historized tags from the ExaOPC Servers comprising the redundancy pairs, in a timely manner.

2.2 Logged Errors

Exaquantum errors with EventID:62915 are logged in the application event log:

Q:\Exaquantum\QOpcManager\QOPCDAManager\OPCHDAServer.cpp


Line 221 : OPCDAManager general error :: GetItemHandles() failed, node = OPCSERVER, progid = Yokogawa.ExaopCHDARD1 hr = 0x8001011f : R3.30 : 2022/10/05 07:58:10.981

2.3 Resolution

To address the issue, increase the ExaOPC-RD HDA timeouts on the Exaquantum server as follows:

Server	Registry name	Increased setting	Default setting
HDARD1/2	OPCAccessTimeOut	20 seconds (20000 Decimal)	5 seconds

The keys for each server in each RD pair are located under HKEY_LOCAL_MACHINE\SOFTWARE\WOW6432Node\YOKOGAWA\Exaopc\OPCRD\



The Exaquantum services should be stopped and the server restarted for the changes to take effect.

2.4 Additional Steps (if required)

If the issue persists:

- With the same error (EventID:62915):

Q:\Exaquantum\QOpcManager\QOPCDAManager\OPCHDAServer.cpp

Line 221 : OPCDAManager general error : : GetItemHandles() failed, node = OPCSERVER, progid = Yokogawa.ExaopcHDARD1 hr = 0x8001011f : R3.30 : 2022/10/05 07:58:10.981

the HDARD1/2 timeout registry key (OPCAccessTimeOut) should be adjusted further by a few more seconds.

The Exaquantum services should be stopped and the server restarted each time a change is made.


- With a different error (EventID:58423):

Q:\Exaquantum\QHDABroker\HDA ServHandler.cpp

Line 309 : Request for HDA data timed out : OPCSERVER ProgID=Yokogawa.ExaopcHDARD1 : R3.30 : 2022/11/30 06:32:50.878

The Exaquantum History Catch-up timeout needs to be adjusted.

This can be achieved by changing the value of HKLM\SOFTWARE\WOW6432Node\Quantum\Server\Catchup\CatchupReadTimeout registry key.



The value is set to 10 by default and increments of 5 are suggested up to a maximum value of 30.

Each change should be accompanied by a restart of the Exaquantum services.

If the issue is not resolved, please contact support at support@ymx.yokogawa.com

Chapter 3 Further Reading

More support is available at www.ymx.yokogawa.com/support or from support@ymx.yokogawa.com email address.

Copyright and Trademark Notices

© 2022 Yokogawa Electric Corporation

■ All Rights Reserved

The copyright of the programs and online manuals contained in the software medium of the Software Product shall remain with YOKOGAWA.

You are allowed to print the required pages of the online manuals for the purposes of using or operating the Product; however, reprinting or reproducing the entire document is strictly prohibited by the Copyright Law.

Except as stated above, no part of the online manuals may be reproduced, transferred, sold, or distributed to a third party in any manner (either in electronic or written form including, without limitation, in the forms of paper documents, electronic media, and transmission via the network).

Nor it may be registered or recorded in the media such as films without permission.

■ Trademark Acknowledgements

- CENTUM, ProSafe, Exaquantum, Vnet/IP, PRM, Exaopc, Exaplog, Exapilot, Exasmoc and Exarqe are registered trademarks of Yokogawa Electric Corporation.
- Microsoft, Windows, Windows Server, SQL Server, Excel, Internet Explorer, SharePoint, ActiveX, Visual Basic, Visual C++, and Visual Studio are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Adobe and Acrobat are registered trademarks of Adobe Systems Incorporated and registered within particular jurisdictions.
- Ethernet is a registered trademark of XEROX Corporation.
- All other company and product names mentioned in this manual are trademarks or registered trademarks of their respective companies.
- We do not use TM or ® mark to indicate those trademarks or registered trademarks in this manual.
- We do not use logos in this manual.

Highlights

The Highlights section gives details of the changes made since the previous issue of this document.

- **Summary of Changes**

This is Issue 1.0 of the document related to Product Library version 1.0.

- **Detail of Changes**

The changes are as follows:

Chapter/Section/Page	Change